

Honda Dashboard Warning Lights Quick Reference Guide

How to Use This Chart:

- Red lights: Stop immediately and seek service.
- Amber/Yellow lights: Check soon or schedule maintenance.
- Green/Blue lights: Informational - system active.

Keep this chart in your glove compartment or printed for easy access.

Red Warning Lights (Immediate Attention)

- Check Engine / MIL / CEL: Stop safely, inspect or service.
- Oil Pressure: Stop, check oil level.
- Battery / Charging: Inspect alternator/battery.
- Brake / ABS: Stop safely, check brake system.
- Airbag / SRS: Service immediately.
- Engine Temperature: Stop, allow engine to cool.

Amber / Yellow Warning Lights (Caution / Service Soon)

- Check Engine (minor): Inspect soon.
- Tyre Pressure (TPMS): Inflate tyres to recommended PSI.
- Maintenance Required: Service within next 500-1000 miles.
- Driver-Assist Alerts: Check system.

Green / Blue Indicator Lights (Informational / Active Systems)

- Turn Signals: Normal operation.
- High-Beam / DRL: Normal operation.
- Cruise Control: System active.
- Eco Mode: Economy driving mode.
- Stability Control: System active, no action needed.

Fluids & Maintenance Alerts

- Low Fuel: Refuel soon.
- Washer Fluid: Refill fluid.
- Coolant: Check level, inspect radiator.
- Oil Change: Service engine oil.
- Transmission / Hybrid: Inspect or service.

Convenience / Reminder Indicators

- Seatbelt: Buckle up.
- Door / Trunk / Hood Ajar: Close before driving.

- Parking Brake: Release before driving.
- Smart Entry / Immobilizer: Ensure key present.

Tips for Drivers

- Keep tyres properly inflated and fluids checked weekly.
- Perform scheduled maintenance to prevent red/amber alerts.
- Familiarize yourself with startup self-check lights.
- Print or laminate this PDF for long-term reference.